



DMX Chart

Showcontroller

**16 bit Mode
27 Channels, Node Mode**

Channel	Function	Value from	Value to	Content	Suggested Default
1	Scene / Cue Bank	0	31	Bank 1	
		32	63	Bank 2	
		64	95	Bank 3	
		96	127	Bank 4	
		128	159	Bank 5	
		160	191	Bank 6	
		192	223	Bank 7	
		224	255	Bank 8	
2	Scene / Cue Bank Page	0	49	Bank page 1	
		50	99	Bank page 2	
		100	149	Bank page 3	
		150	199	Bank page 4	
		200	255	Bank page 5	
3	Scene / Cue Selection		6	Scene 1	8
			13	Scene 2	
			17	Scene 3	
			21	Scene 4	
			25	Scene 5	
			29	Scene 6	
			34	Scene 7	
			38	Scene 8	
			42	Scene 9	
			46	Scene 10	
			50	Scene 11	
			54	Scene 12	
			58	Scene 13	
			62	Scene 14	
			67	Scene 15	
			71	Scene 16	
			75	Scene 17	
			79	Scene 18	
			83	Scene 19	
			87	Scene 20	
			91	Scene 21	
			95	Scene 22	
			99	Scene 23	
			104	Scene 24	

Channel	Function	Value from	Value to	Content	Suggested Default
			108	Scene 25	
			112	Scene 26	
			116	Scene 27	
			120	Scene 28	
			124	Scene 29	
			128	Scene 30	
			132	Scene 31	
			137	Scene 32	
			141	Scene 33	
			145	Scene 34	
			149	Scene 35	
			153	Scene 36	
			157	Scene 37	
			161	Scene 38	
			165	Scene 39	
			170	Scene 40	
			174	Scene 41	
			178	Scene 42	
			182	Scene 43	
			186	Scene 44	
			190	Scene 45	
			194	Scene 46	
			198	Scene 47	
			202	Scene 48	
			207	Scene 49	
			211	Scene 50	
			215	Scene 51	
			219	Scene 52	
			223	Scene 53	
			227	Scene 54	
			231	Scene 55	
			235	Scene 56	
			240	Scene 57	
			244	Scene 58	
			248	Scene 59	
			252	Scene 60	
4	Speed	0	255		82

Channel	Function	Value from	Value to	Content	Suggested Default
5	Dimmer / Intensity coarse	0	255		
6	Dimmer / Intensity fine	0	255		
7	Size X coarse	0	255		153
8	Size X fine	0	255		
9	Size Y coarse	0	255		153
10	Size Y fine	0	255		
11	PAN position coarse	0	255		128
12	PAN position fine	0	255		128
13	TILT position coarse	0	255		128
14	TILT position fine	0	255		128
15	Rotate X coarse	0	255		
16	Rotate X fine	0	255		
17	Rotate Y coarse	0	255		
18	Rotate Y fine	0	255		
19	Rotate Z coarse	0	255		
20	Rotate Z fine	0	255		
21	Color selection coarse	0	255		
22	Color selection fine	0	255		
23	Zoom coarse	0	255		
24	Zoom fine	0	255		
25	Color Channel Red	0	255		
26	Color Channel Green	0	255		
27	Color Channel Blue	0	255		

Laserworld AG
Kreuzlingerstrasse 5
8574 Lengwil
Switzerland

Board of Directors: Martin Werner

Registered office:
8574 Lengwil / Switzerland
Company number: CH-440.3.020.548-6
Commercial Registry Kanton Thurgau
CEO: Martin Werner
VAT no. (Switzerland): 683 180
UID (Switzerland): CHE-113.954.889
VAT no. (Germany): DE 258030001
WEEE-Reg.-No. (Germany): DE 90759352

www.laserworld.com
info@laserworld.com

representative according to EMVG:
LaserAnimation Sollinger GmbH
Mühlbachweg 2
83626 Valley, Germany