## CS-2000RGB FX MK3 DMX Channel chart:

| Channel | | Value | Function |
|---|---|---|---|
| CH1 | Intensity | 0 | Laser Off, CH2-17 not available |
| | | 1～255 | RGB intensity 0~100% (also affects sound and auto mode) |
| CH2 | Pattern selection | 0～255 | Pattern selection |
| CH3 | Pattern rotation | 0～127 | Rotation angle selection |
| | | 128～191 | Rotation anti-clockwise speed selection |
| | | 192～255 | Rotation clockwise speed selection |
| CH4 | Pattern X-axis flip | 0～127 | X-axis flip position selection |
| | | 128～255 | X-axis flip speed selection |
| CH5 | Pattern Y-axis flip | 0～127 | Y-axis flip position selection |
| | | 128～255 | Y-axis flip speed selection |
| CH6 | X-axis movement | 0～127 | X-axis movement position |
| | | 128～255 | X-axis movement speed |
| CH7 | Y-axis movement | 0～127 | Y-axis movement position |
| | | 128～255 | Y-axis movement speed |
| CH8 | X-axis pattern size | 0～255 | Big to small |
| CH9 | Y-axis pattern size | 0～255 | Big to small |
| CH10 | Pattern gradient | 0～255 | Gradient speed |
| CH11 | Scanning speed | 0～127 | Scanning speed |
| | Point effect | 128～255 | Point speed |
| CH12 | Color mode | 0～24 | No change |
| | | 25～199 | Color selection |
| | | 200～224 | Color change effect |
| | | 225～255 | Flowing watercolor change effect |
| CH13 | Color speed | 0～255 | From slow to fast |
| CH14 | Operation mode | 0～199 | DMX mode, CH1-CH17 available |
| | | 200~224 | Sound mode, CH1, CH15-CH17 available |
| | | 225~255 | Automatic mode, CH1, CH15-CH17 available |
| CH15 | Red brightness adjust | 0～255 | Red brightness adjust 100~0% (also affects sound and auto mode) |
| CH16 | Green brightness adjust | 0～255 | Green brightness adjust 100~0% (also affects sound and auto mode) |
| CH17 | Blue brightness adjust | 0～255 | Blue brightness adjust 100~0% (also affects sound and auto mode) |